

## MS-7120-38 USB Scanner for OPOS

1. HSM USB Serial Driver version 3.5.5 과
2. MetrOPOS Driver 를 먼저 인스톨합니다.
3. Barcode 를 순서대로 Scan 합니다.


### USB Serial (POS-USB) connection.

Before a USB scanner configured for USB serial can work with OPOS it needs to be programmed with specific OPOS formatting. As mentioned previously RS232 scanners can be programmed directly from OPOS Administrator using the 'Program' button which will download the OPOS settings to the device.



For USB Serial however the scanner needs to be programmed manually. This can be done using Metroset if you know the required settings or by scanning the codes below in the numbered order.

1.



4.



7.



2.



5.



3.



6.



Once the scanner is programmed, provided the USB driver is correctly installed, the scanner will automatically install and will appear in the 'Ports' section of Windows Device Manager as shown below.

Enable Bi-Directional USB  
Serial Emulation Mode



3 3 1 6 4 6 0