

Honeywell Xenon 1900

Programming the Interface



PAP232.
HS232 Interface

Baud Rate 115,200 bps
Data Format 8 Data bits, no parity, 1 stop bit



TRMUSB130.
USB Serial

USB Serial

Default All **Code 39** Settings



C39DFT.



C39CK20.

* No Check Character

Interleaved 2 of 5 On/Off



I25ENA1.

* On

Code 39 On/Off



C39ENA1.

* On



C39ASC1.

Full ASCII On



I25CK20.

* No Check Digit

Default All **Code 93** Settings



C93DFT.

Code 93 On/Off



C93ENA1.

* On

<Default All Code 11 Settings>



C11DFT.

Code 11 On/Off



C11ENA1.

On

<Default All Code 128 Settings>



128DFT.

<Default All UPC-A Settings>



UPADFT.

<Default All UPC-E Settings>



UPEDFT.

UPC-E Expand expands the UPC-E code to the 12 Digit
UPC-A format, Default=OFF



UPEEXP1.

On

Code 128 On/Off



128ENA1.

* On

UPC-A On/Off



UPAENA1.

* On

UPC-A Check Digit



UPACKX0.

Off



UPEEN01.

* UPC-E0 On

UPC-E Check Digit Off



UPECKX0.

Off